

Install 8.27 RIP Notice:

This RIP software will be mistaken for a virus or Trojan by the computer, but it is safe.

Steps:

1. If you have anti-virus program in your computer, just exit it at the moment or allow this program.
2. Decompress the “Acrorip 8.27RIP software” file on the desktop.
3. Click “set up”.
4. First continue to click “Acrorip 8.27 RIP software”. Follow next to go on, if appear anti-virus signal, please add trust.
5. Then two icons appear “P” and “W” on the desktop.
6. Insert the dongle on the computer, and then open RIP , try to open an image in RIP.
7. Check and set the settings in RIP, after that try to print.